

Lifeboat - Freefall - Tanker Version - 490 TV (type JY-FF-4.9)

Specifications:		
Length:	4,90	(meters)
Height:	3,10	(meters)
Width:	2,25	(meters
Max persons:	16	
Weight boat:	2850	(kilogram)
Weight davit system:	4320	(kilogram)
Certified drop height:	16 m	
Propulsion type:	Propeller	
Engine type:	BUKH DV29 RME	
Towing force:	2,8kN	
Speed:	6	(knots)
Length of ramp:	5.90	(meters)
Concerl Decemintions		

General Description:

This totally enclosed free fall lifeboat tanker version is equipped with an inboard diesel engine.

Hull and super structure:

The boat is made out of fire-retardant glass fiber reinforced polyester, also known as GRP. The main parts are laminated independent molds. To assure buoyancy and strength, foam is injected into certain areas between the inner liner and the hull. Longitude bulkheads and transverse bulkheads, secure the strength of the hull. Extra strengthening is built in to the bow area to absorb the forces from water during diving. The boat is made with anti-skid on all walking surfaces, inside and outside. A fender made out of synthetic rubber is mounted on port and starboard side. Stainless steel screws connect this fender to the hull.

External steel parts quality:	316 L
Inside steel parts quality:	304
Color:	
Hull outside:	Gel coat resin with orange colour.
Hull inside:	Painted in grey white colour.
Hook system:	

FF Hook system: JX-2

Free-fall operations:

The free-fall hook is located at the stern of the boat. The helmsman controls the release device. One set of emergency release system is also provided. The two systems operate independent of each other. The primary release device is located in the boat cabin next to the helmsman; the emergency release device is located next to the entrance door.

The hoisting and gravity lowering are operated by two double wire ropes attached to three lifting eyes mounted on top of the superstructure.

The hook is crafted out of galvanized steel, with stainless steel as an option.



Engine specifications:

Maker:	BUKH	
Model:	DV29 RME	
Туре:	Direct injection, 4 stroke, 2 cylinders	
Power:	29 hp (21.3 kW)	
Fuel quality:	BS 2869 Class A	
Fuel consumption:	7,8 L/H	
Fuel capacity:	180 ltr	
Starting method:	Electric starting/ emergency manual starting	
Alternator:	14V, 50 Amp, 700 W	
Starter:	12 V, 1,36 hp (1,0 kW)	
Optional engines:	ZHENJIANG SIYANG 380J-3 or YANMAR 3JH30A	

Spare parts and tools of one set with contents of:

- Adjustable spanner
- Adjustable plier
- Double spanner 8mm x 10mm, 13mm x 17mm , 19mm x 22mm, 24mm x 27mm
- Screwdriver
- Allen key , 10mm , 8mm , 5mm , 4mm
- Oil can 0,3ltr
- 1 X V- belt
- 1 x fuel filter insert
- 1 x lube oil filter

Transmission: Disengage able shaft coupling

- The speed of the engine and the control of ahead and astern are all controlled through a cable by the helmsman from the helmsman's position.
- Closed fresh water and keel cooling system with anti-freeze liquid.
- The engine is supplied with two independent starting batteries. It can be reached through a removable inspection cover, made out of fire retardant and heat-insulting material.
- The engine is installed with a silencer and exhaust pipe, which is made out of stainless steel and is wrapped with heat-insulating material.

LIFESAVING

Water-spraying system:

A water spray system is installed for fire protection. The spray system consists of an engine driven pump, which takes seawater from an intake location under the boat ensuring that no flammable liquid is drawn into the system. The spray system provides water over the entire surface of the boat (1300L/min).

Air supply system:

The compressed air system installed has a sufficient capacity to provide air for the maximum number of persons and engine combustion for a minimum of 10 minutes. It also establishes an overpressure inside the boat to prevent ingress of toxic fumes or gas. Provisions have been made to recharge the air cylinders from the ship's compressed air system.

A pressure relief value is mounted on the aft bulkhead's port side. The value prevents the cabin from becoming dangerously over pressured when the emergency air system is in operation. Natural Ventilation is achieved via an automatic value located on the stern embarkation door. The value also prevents the cabin from becoming dangerously under pressured while the engine is running.

Operation:

The main operation of the boat is carried out from the helmsman's position behind the console system fitted mid-ship.

The following equipment is fitted on the console:

- Electric start/stop
- Power indicator
- High cooling temperature alarm
- Low oil pressure alarm
- Closed fresh water and keel cooling system with anti-freeze liquid.
- The engine is supplied with two independent starting batteries. It can be reached through a removable inspection cover, made out of fire retardant and heat-insulting material.
- The engine is installed with a silencer and exhaust pipe, which is made out of stainless steel and is wrapped with heat-insulating material.
- The speed of the engine and the control of ahead and astern are all controlled through a cable by the helmsman from the helmsman's position.

Fuel

The fuel oil tank is made out of stainless or galvanized steel. The capacity of the fuel tank is sufficient to run the fully loaded lifeboat at 6 knots for a period of net less than 24 hours. The tank is also fitted with an exhaust outlet led to the outside of the boat.

Propeller and shaft

The shaft is crafted out of stainless steel; its couplings and support at the two ends are made out of bronze. The propeller is made out of nickel aluminium bronze and is protected by a GRP duct. All the parts and the propelling system are protected.

World Wide Distribution - Factory



Steering system:

Steering can be achieved by turning a duct rudder that surrounds the propeller. This duct is made out of GRP and will also protect the propeller. The steering rod and its supports are made out of stainless steel. The duct rudder can be operated through a cable by the wheel from the helmsman's position.

In case of failure of the steering flexible cable, a stainless emergency tiller this rudder is stowed close to the steering rod may directly control the rudder.

Equipment:

The equipment required by LSA regulation is provided.

Electrical equipment:

Electrical Equipment:

The following electrical equipment is installed in the free fall lifeboat:

- Two separate batteries of free maintenance type with 90 AH. The batteries are stowed in a GRP container with a ventilation pipe, led to the outside.
- Main battery switch
- CD4212.2, 42V type charger connected with Ladix cable system to external power supply. Contacts are of quick release type.
- Canopy light, Hand held searchlight, marking light
- Compass with compass light
- Switch panel with integrated fuses

The electric equipment within the lifeboat is built to IP56 standard.

Fitting and equipment on lifeboat:

•	Release hook	1 pce
•	Painter release device operated from inside lifeboat	1 set
•	Fender (synthetic rubber)	1 set
•	Steering gear (push-pull type)	1 set
•	Ventilator (manual closing type when capsizing)	1 pce
•	Equipment according to SOLAS/LSA	1 set
•	Bouyant lifeline around the gunwall	2 pcs
•	Bilgepump – Manual	1 pce
•	Drain plug	1 pce



Identification:

The identification plate is fitted next to the helmsman's position. This identification plate describes the following: Type of boat, inspection mark, serial number, main dimensions number of persons, fully loaded weight, date of completion, name of manufacturer.

The ship's name, port of registry and number of persons are marked on port and starboard bow. The call sign and boat number are located on top of the enclosure. Retro-reflective tapes are fitted on top, on the sides and on the stern of the enclosure.

There are symbols of life-saving appliances provided in the vicinity of the helmsman's position and nearby each storage compartment.

Documentation:

The following documents are submitted after delivery:

- Product specifications
- General arrangement drawings
- User instruction manuals
- Instructions for on-board maintenance of lifeboat

Warranty:

The warranty period is normally limited to max, 18 months from delivery of equipment, or 12 months from delivery to vessel or owner.

Regulations:

The (Free fall lifeboat 490TV ,JY-FF 4.9) fully complies with the latest SOLAS requirements and LSA Code and resolution MSC.274(85) and MSC.272(85)

The (Free fall lifeboat 490TV ,JY-FF 4.9) will be certified and approved by various classification bureaus (on request) and European Council Directive 96/98 EC on Marine Equipment (M.E.D).1996 amendments to the International Convention for the safety of Life at Sea 1974 and LSA Code.MSC.218(82), MSC.226(82), MSC.272(85).

Optional:

- VHF Radio
- Engine heather
- Cabin heather
- I EPIRB (Emergency position indicating radio beacon)
- SART (Search and rescue transponder)
- Electrical bilge pump
- Bow thruster
- Intercom system

World Wide Distribution - Factory



Standard equipment according to SOLAS:

Item name :	Qty :	Remarks:
Rowing oar	2	wood and length 2.8m
Clutch for oar	2	fitted on hull (stainless steel)
Boat hook		Length 2,5m (wood)
Buoyant bailer	1	with lanyard (plastic)
Bucket	2	with lanyard (plastic)
Survival manual	1	English/ flag state language
Magnetic compass	1	fitted on hull (with illumination)
Sea anchor	1	-
Painter	2	synthetic rope (20mm Diax 50m)
Hatchet	2	with lanyard (galv. Forced steel)
Fresh water		3ltr /person
Dipper		with lanyard (rustproof)
Drinking cup	1	with graduate (plastic)
Emerg. Food ration	-	10000 KJ/ Person
Rock. Parachute sign.	4	-
Hand flare	6	-
Buoyant smoke sign	2	-
Waterpr Elec. torch	1	with 1 spare bulb and 1 set of spare batteries
Daylight signal mirror	1	with instruction
Life saving sin.table	1	waterproof paper
Whistle	1	or equivalent (plastic)
First aid kit	1	1 set (in plastic waterproof container or bag)
Anti-seasickness medicine	-	12 doses / person
Seasickness bags	-	1 pcs / person
Jack knife	1	with lanyard
Tin opener	3	galvsteel
Buoyant rescue quoit	2	plastic polypropylene rope (4mm dia.x30m)
Manual pump	1	fitted on hull
Fishing tackle	1	-
Portable extinguisher	1	dry powder type (oil extinguishing)
Search light	1	portable type fitted on hull
Radar Reflector	1	-
Thermal protective aid	-	15% of lifeboat capacity
Rain water tank	1	5 liter capacity
Boarding ladder	1	wood synthetic rope

World Wide Distribution - Factory Beatrixhaven 19, 4251 NK WERKENDAM - The Netherlands - Tel: +31 183 691 010 - Email: info@eurooffshore.nl - www.eurooffshore.com